


Touchscreen Calibration

Fusion Maker - Fusion Edge - Fusion Pro 24 & 36



Touchscreen Calibration

The display calibration ensures the accuracy of the touchscreen when selecting options and settings on the display. The display calibration rarely needs to be completed and should only be performed if accuracy or touch response issues are observed.


1. At the display panel, press the gear icon in the upper right-hand corner of the display to open the Settings menu:



2. Press and hold the word "Settings" on the touchpad to gain access to the Advanced Settings menu:



3. In the Advanced Settings menu, select Calibrate Display:




17000 - Touchscreen Calibration


- The engraver will prompt the user to press a target in each corner of the display.
- Press the target in the upper-left hand corner:




- Press the target in the upper right hand corner:



- Press the target in the lower left hand corner:



- Press the target in the lower right hand corner:



- Once the last target is pressed, the engraver will return to the Advanced Settings menu. There is no success message for this calibration procedure.

If further assistance is required, contact Epilog Laser Technical Support by phone at 303-215-9171, or by email at tech@epiloglaser.com.